

OUTDOOR SOL-ARK 8K-2P INSTALL GUIDE & OWNER'S MANUAL

UPON RECEIVING SHIPMENT	
SPEC SHEET	5
WIRE GAUGE GUIDE (COPPER)	7
WIRING DIAGRAMS	
PHYSICAL INSTALLATION	
Inverter Components	12
DECIDING BACKUP CIRCUITS	12
SINGLE SYSTEM INSTALLS	13
Mounting the Sol-Ark	13
INTEGRATING BATTERIES (SOL-ARK POWERED "OFF")	13
E.M.P Systems Only	14
CONNECTING SOLAR PANELS	14
INTEGRATING A GENERATOR	15
INTEGRATING SENSORS AND ACCESSORY PLACEMENT	16
Powering-Up and Testing the Sol-Ark 8K	18
CHECK THE VOLTAGE ON EACH PV INPUT CIRCUIT	18
WI-FI / INTERNET CONNECTION	
Remote Monitoring Setup	19
IP Address Setup Instructions (PC or Smart Phone)	22
GUI SCREENS	
PROGRAMMING GUIDE	
Main Screens (Touchscreen)	
BASIC SETUP	
System Alarms	
BATTERY SETUP	29
GRID SETUP	
Limiter Sensor Automatic Setup	34
	25
	······ 35
GRID-TIE / NO DATTERT INSTALL TIPS	
BATTERIES	
BATTERY CHARGING INFORMATION	36
MODBUS/RJ45 APPLICATION NOTE	39
TROUBLESHOOTING GUIDE	
TROUBLESHOOTING PHASING ISSUES	
The obleshoot had that and issues in the international states and issues and international states and issues and is	41
Sol-Ark 8K Error Codes	41 42
SOL-ARK 8K ERROR CODES	41 42 43
SOL-ARK 8K ERROR CODES	41 42 43



Disclaimer

UNLESS SPECIFICALLY AGREED TO IN WRITING, SOL-ARK:

(a) MAKES NO WARRANTY REGARDING THE ACCURACY, SUFFICIENCY, OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN ITS MANUALS OR OTHER DOCUMENTATION.

(b) ASSUMES NO RESPONSIBILITY OR LIABILITY FOR LOSS OR DAMAGE, WHETHER DIRECT, INDIRECT, CONSEQUENTIAL, OR INCIDENTAL, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER'S RISK.

Sol-Ark cannot be responsible for system failure, damages, or injury resulting from improper installation of their products.

The information included in this manual is subject to change without notice.

This version is for **OUTDOOR MODELS ONLY**; previous hardware versions of the Sol-Ark 8K are not compatible with the wire diagrams and instructions contained herein.

Cor	ntact	Us:

PHONE EMAIL WEBSITE 1-972-575-8875 x2 SUPPORT@SOL-ARK.COM WWW.SOL-ARK.COM

Warning Symbols

This symbol indicates information that, if ignored, could result in minor injury or damage to the equipment.
This symbol indicates information that, if ignored, could result in serious injury, damage to the equipment, or death.
This symbol indicates information that is important but not hazard-related.

Warnings

Read this entire document before installing or using the Sol-Ark 8K inverter. Failure to follow any of the instructions or warnings in this document can result in electrical shock, serious injury, or death. Damage to the 8K inverter is also possible, potentially rendering it inoperable.



High Life Risk Due to Fire or Electrocution – ONLY qualified persons should install the Sol-Ark 8K inverter.



The system must have Ground connections and Neutral connections. Ground <u>MUST</u> be bonded to Neutral <u>ONLY ONCE</u> in the circuit.



Solar PV+/PV- are <u>UNGROUNDED</u>. Note, you may ground <u>PV Racking/Mounts</u>, but doing so directly to the Sol-Ark will likely result in damage in the case of a direct lightning strike to the PV array.



DO NOT connect the grid to the Load Output Breaker.



DO NOT reverse the polarity of batteries. Damage <u>WILL</u> occur.



DO NOT exceed more than 500Voc on any MPPT on the Sol-Ark.



MUST use Strain Reliefs ON ALL wires entering/exiting the Sol-Ark 8K user area.



MUST use conduit (or double insulated wire) for AC Wires entering/exiting Sol-Ark 8K user area.





Inspect Shipment

A. Compare the package condition to the condition of the package in the photo we sent you before it left our facility.



You must note any damage due to shipping with delivery driver before accepting the package otherwise the shipping company will deny any claim.

B. If damaged, contact us immediately at 972-575-8875 Ext. 3

Component Guide

- A. Limiter Sensors included: 5/8" CT sensors x2 (Included)
- B. Limiter Sensors if purchased: 15/16" CT sensors x2 (Sold Separately)
- C. Limiter Sensors if purchased: 2" CT sensors x2 (Sold Separately)
- D. Battery Temperature Sensor: for voltage adjustment
- E. Battery Cable Toroid x2
- F. CAT 5 cable for parallel communications
- G. WIFI Dongle: For software updates and remote monitoring (use M4x10 screws to hold in)
- H. French Cleat: For wall mounting the Sol-Ark 8K





8K-2P-N UL Model: "Sol-Ark-8K-48-ST"

•		
SOI-A	rk	
-		
9 8 9		
0	~ .	

Solar In	nput Power 11,000W		
Max Allowed PV Power	5,500W + 5,500W = 11,000W		
Max PV Power Delivered to Battery & AC Outputs	8,000W		
Max DC Voltage (Voc)	500V @ 18A, 450V @ 20A		
MPPT Voltage Range	150-425V		
Starting Voltage	125V		
Number of MPPT	2		
Max Solar Strings Per MPPT	2		
Max DC Current per MPPT (Self Lim- iting)	20A		
Max AC Coupled Input (Micro/String Inverters)	9,600W		

AC Output Power 8kW On-Grid & Off-Grid

Connections	120/240/208V Split Phase
Continuous AC Power to Grid (On-Grid)	8,000W 33.3A-L (240V)
Continuous AC Power to Load (Off- Grid)	8,000W 33.3A-L (240V)
Surge AC Power 10sec Surge AC Power 100ms	16,000VA L-L (240V) 25,000VA L-L(240V)
Fault Current 100ms	104A L-L (240V)
Parallel Stacking	No
Frequency	60/50Hz
Continuous AC Power with Grid or	15,120W 63A L-L (240V)
Generator	7,560W 63A L-N (120V)
CEC Efficiency	96.5% (Peak 97.5%)
Idle Consumption Typical—No Load	60W
Sell Back Power Modes	Limited to Household/Fully Grid-Tied
Design (DC to AC)	Transformerless DC
Response Time (Grid-Tied to Off-Grid)	4ms
Power Factor	+/- 0.9 - 1.0

Battery (optional) Ou	itput Power 8,000W		
Туре	Lead-Acid or Li-Ion		
Nominal DC Input	48V		
Capacity	50 — 9900Ah		
Voltage Range	43.0 — 63.0V		
Continuous Battery Charging Output	185A		
Charging Curve	3-Stage w/ Equalization		
Grid to Batt Charging Efficiency	96.0%		
External Temperature Sensor	Included		
Current Shunt for Accurate % SOC	Integrated		
External Gen Start Based on Voltage or %SOC	Integrated		
Communication to Lithium Battery	CanBus & RS485		

General	
Dimensions (H x W x D)	30.0" x 18.3" x 10.0"
Weight	78 lbs
Enclosure	NEMA 3R
Ambient Temperature	-25-55°C, >45°C Derating
Installation Style	Wall-Mounted
Wi-Fi & LAN Communication	Included
Standard Warranty (verified by HALT Testing)	5 Years (10 yr ext)

Contact Sales@sol-ark.com for 10 year extension

Protections & Certifications	
Electronics Certified Safety by SGS Labs to NEC & UL Specs - NEC 690.4B & NEC 705.4/6	Yes
Grid Sell Back — UL1741-2010/2018, IEE- E1547a-2003/2014, FCC 15 Class B, UL1741SA, CA Rule 21, HECO Rule 14H	Yes
PV DC Disconnect Switch — NEC 240.15	Integrated
Ground Fault Detection — NEC 690.5	Integrated
PV Rapid Shutdown Control — NEC 690.12	Integrated
PV Arc Fault Detection — NEC 690.11	Integrated
PV Input Lightning Protection	Integrated
PV String Input Reverse Polarity Protection	Integrated
AC Output Breakers - 63A	Integrated
250A Battery Breaker / Disconnect	Integrated
Surge Protection	DC Type II / AC Type II



Sol-Ark 8K Torque Values Application Note

Load Breaker	26.5 IN Lbs	3 NM
Grid Breaker	26.5 IN Lbs	3 NM
Gen Breaker	26.5 IN Lbs	3 NM
Neutral / Ground Busbars	26.5 IN Lbs	3 NM
Cover Screws	26.5 IN Lbs	3 NM
Battery Connection	90.0 IN Lbs	10 NM



Do Not Use Impact Drivers to Tighten Any Fasteners on the Sol-Ark.



Wire Gauge Guide (copper)







These Single Line Diagrams (SLDs) are <u>examples</u> of common use-cases for Sol-Ark inverters.

Sol-Ark does not provide custom diagrams; however, you may contact <u>support@sol-ark.com</u> for any questions about an existing SLD.



Sol-Ark Off-Grid Standard Wire Diagram 120V/240V



Diagram 3











Note: PV fuses are only required for >2 strings per MPPT



Inverter Components



- A. LCD Touch Screen
- **B.** Power Button
- C. PV DC Disconnect Switch
- D. 250A Battery Breaker
- E. Battery Terminals (+/-)

- F. Sensor Pin-Out Board
- G. Comms/Paralleling Ports
- H. AC Breakers (Grid 63A/Gen 50A/Load 63A)
- I. Neutral/Ground Bus Bar
- J. MPPT Charge Controllers

Deciding Backup Circuits

- A. We recommend subpanels and require them if you have Arc-Fault / GFI breakers
- B. Ensure you keep the inverter within its amperage limits
 - ON-Grid = 63A Continuous (pass-through)
 - OFF-Grid = 33.3A Conutuous | 67A Peak (10s) | 104A Peak (100ms)
- C. Verify each load circuit by measuring typical and max Amps with a clip-on Amp meter. Amps x 120V = Watts
- D. Install a subpanel for backup loads if you have Arc-Fault / GFI breakers, NOT a multi-circuit transfer switch

Single System Installs

- A. Install Double Pole 60A breaker in Main Panel for Grid In/Out
- B. Best practice to install at the opposite end of the bus bar from the main breaker, which is usually at the bottom of the breaker panel (see figure above)

Mounting the Sol-Ark

- A. Keeping in mind Sol-Ark's dimensions, find a suitable location for the system (s)
- B. NEMA 3R rating for Outdoor installations



- C. **PROTECT the LCD screen from excessive UV exposure**
- D. System weight = 78lbs (35kg). Securely attach to the wall. Affix a mounting board to studs using 6-8 screws
- E. Using 2-3 screws + washers (choose screw length and surface type) to mount the French Cleat to the board/wall
- F. Mount Sol-Ark on the installed French Cleat / Ensure Sol-Ark is level and sits properly
- G. Add two screws for the bottom mount

Integrating Batteries (Sol-Ark POWERED "OFF")

- A. Connect batteries to Sol-Ark as shown in Fig. B below
- B. Install included toroids (Part e. on pg. 4) on battery input cables as shown in Fig. A to the right
- C. Ensure the built-in battery disconnect is OFF while connecting batteries, or arcing may occur





Fig. A

E.M.P Systems Only

Suppressor installation

• If your system was purchased with Lightning / EMP Hardening, the vast majority of protection is in the Sol-Ark. However, you also have EMP suppressors that get installed on the power cords of appliances that are connected to the transfer switch. Although not critical, it is recommended they be installed as close as possible to the appliance.

• You also have EMP suppressors that get installed on both solar panel wires with a zip tie. Closer to the panel is better. If you purchased the panels from us, we already installed >150kV/m protection inside the solar panels.







If using panels not from Sol-Ark

Connecting Solar Panels

- A. Sol-Ark has DUAL MPPTs for two separate PV input pairs
- B. MAX PV input = 11kW (± 5%) / system | 5.5kW / MPPT | MAX 500V_{oc} PV | MAX I_{sc} / MPPT 25A (limiting to 20A)



- C. Parallel strings per MPPT must be the same Voltage
 - i. PV1 A/B must be the same voltage if using both strings
 - ii. Panels on the same MPPT CAN face different directions
- D. Ground the panel MOUNTS/FRAMES to any ground in the Home via 12AWG wire
- E. IF using Y-Connectors: Running two strings in parallel, totaling 20A (self-limiting)
- F. Connect the solar panel strings as indicated by the following diagram:





wires

panels or 175V

Each string can use separate

String minimum is usually 5

December 2nd, 2022

Integrating a Generator

Generators < 10kW (GEN Breaker)— See Diagram 1-2

- A. ONLY supports 240V / 208V generators | 50A breaker
- B. Connect the generator output to the "GEN" input breaker in the Sol-Ark 12K user area
- C. THD of less than 15% preferred but not required

Standby Generators > 10kW (GRID Breaker)— See Diagram 1 (OFF-GRID)

- A. Supports 220V / 240V / 208V generators | Depends on "Grid Type" selection | 63A breaker
- B. Off-Grid / Whole-home Generator on ATS installations require selecting "GEN Connected to Grid Input"

Home Screen \rightarrow Gear Icon \rightarrow Grid Setup \rightarrow Sell Control \rightarrow GEN Connected to Grid Input

C. Off-Grid = turn "Grid Sell" off | Only need CT's (on Gen lines) if using Grid Peak Shaving (see below)



Increase Gen/Sol-Ark efficiency

Select "Limited to Load"
 Select "General Standard"
 Increase Grid frequency range: 55-65H

Weekly Gen Exercise

If the Sol-Ark is up to date with MCU version xx73 or newer, and your generator has two-wire start compatibility, you will experience weekly generator tests.

These tests occur at 8AM (local time) every Monday by default.

The test takes approximately 20 minutes to complete. During that time, the generator will auto-start and auto-stop.

The generator will not provide power during this test. The generator may charge the batteries if the batteries reach designated generator start point, however.

Grid Peak Shaving Mode (For Gen Connected to Grid Breaker)

- A. Prevents the Sol-Ark from overloading generators
- B. Must place the CT sensors so that they measure L1 and L2 of the generator's output, pointing arrows on the CT's towards the generator
- C. Sol-Ark contributes power above the "Power" value threshold to prevent overloading the generator
- D. This mode will auto-adjust the Grid Charge Amperage to avoid overloads

Gen Start V or % (Grid Start if Gen on Grid Breaker)

Value batts need to reach **<u>BEFORE</u>** automatically starting a generator connected to the GEN breaker to charge the battery bank.



Sol-Ark will NOT charge batteries from a generator until the batteries reach this value.

Gen Start A (Grid Start if Gen on Grid Breaker)

This is how many amps **(DC)** you can pull specifically from the Generator to charge the batts. To ensure you do not overload a small Generator, you will want to adjust the GEN or GRID Start A value. *Multiply value by # of Sol-Arks for actual current value into batteries.*

Solar Arc Fault ON Clear Arc_Fault Gen Limit Power 9000W Load Limit Power 8000W Genz Load Limit Sensors CT ratio 2000 CANCEL OK UPS Time 0ms	Display inite internet internet	. an anno .	
Gen Limit Power 9000W 00000 Load Limit Power 8000W 238094 Grid peak-shaving Power 8000W Auto detect Home Limit Sensors CT ratio 2000 CANCEL OK UPS Time 0ms	Solar Arc Fault ON Clear Arc_Fault	ARC paramete 030000 045000	rs
Load Limit Power 8000W 238094 Grid peak-shaving Power 8000W Auto detect Home Limit Sensors CT ratio 2000 CANCEL OK UPS Time 0ms	Gen Limit Power 9000W	000400 000050 000390	
Grid peak-shaving Power 8000W Auto detect Home Limit Sensors CT ratio 2000 CANCEL OK UPS Time Oms	Load Limit Power 8000W	000055 238094	
Auto detect Home Limit Sensors CT ratio 2000 CANCEL OK UPS Time Oms	Grid peak-shaving Power 8000W		
CANCEL OK UPS Time Oms	Auto detect Home Limit Sensors CT ratio	2000	
	CANCEL OK UPS Time	0ms	

Time Advanced Factory Reset Paralle

Batt	Charge	Discharge	S	mart Lo	ad			
StartV	49.0V	49.0V	1	Float V			54.8	V
Start%	6 30%	30%		Absorb	tion V		55.5	v
Δ	40A	100A		Equaliz	ation	V	55.5	v
Ge	n Charge	Grid Charg	e	30 Day	s		0.0 H	lours
Generat	or Excercise	Cycle Day & Tim	e>>	Mon	08	1	:00	20mir
G	en Force	CANCEL			ОК			



Suppose PV production = 0W | Disabled TOU | Enabled Grid/Gen Charge: the batteries will be charged to "full" using the Grid or a Generator (if available) until the battery bank accepts only 5% of its rated capacity in Amperes. This value correlates to roughly 90-93% full for most batteries and is the generator's default "OFF" signal. If producing PV, the system will use PV to charge the batteries to 100% full instead.

Integrating Sensors and Accessory Placement



Sensor Pin Out (Located in Sol-Ark user

(1,2) Batt Temp: Battery Temperature Sensor has no polarity and is needed for voltage correction when using lead acid batteries.

(+3, -4) CT1 & (+5,-6) CT2: Current transformers used for limited to home mode and peak shaving

(7,8) Gen Start Relay: Two wire start for generators, simple open or closed relay

(9,10) Gen On Relay: Not currently used

(B 11, B 12) Emergency Stop: Short these pins to initiate emergency stop. This will shutdown AC output from the inverter and initiate rapid shutdown of the PV.

(+13, -14) Optional 12V input signal for RSD

(+15, -16) 12V power supply for RSD transmitters: such as TIGO and Midnite Rated for a maximum of 1.2W (100mA @12V)

Battery Temperature Sensor

- Place between batteries with tape (See Fig. C).
- This sensor has no polarity and helps perform voltage charging adjustments and capacity calculations.

Note: Lithium Batteries do NOT require a Temperature sensor.

Limiter Sensors (CT Sensors)

- Install sensors on incoming electrical service wires on L1 and L2 (see Diagrams Section)
- Limited To Home Mode (meter zero) and Peak Shaving Modes require CT sensors
- CT winding default ratio is 2000:1; however, this ratio is programmable
- To ensure the sensors will fit, please check the wire size before ordering

GEN Start Signal (Two-Wire)

• The signal comes from a normally open relay that closes when the Gen Start state is active

CANbus & RS485

- To connect batteries to the Sol-Ark 8K via RJ45, you need to splice the end connecting to the Sol-Ark 8K
- Use the middle two conductors
- RS485 is SunSpec draft 4 (will not work with draft 3)

Wi-Fi Antenna (Dongle)

Remote monitoring and software updates require an internet connection through the Wi-Fi dongle



Emergency Stop Signal & PV Rapid Shutdown Signal

Pins 11 and 12 use a normally open & latching switch to connect the two emergency stop pins that cut off the RSD power supply when triggered, thus stopping the inverter AC output.

Pins 15 and 16 provide the 12V / 100mA signal power lost when the Sol-Ark shuts down using the front button.



Emergency Stop Diagram (Only available on select hardware versions | Shown with TIGO TS4)

Rapid Shutdown: TIGO TS4-A-O | TIGO TS4-A-F | TIGO TS4-O | TIGO TS4-O-DUO | APsmart RSD S-PLC / RSD-D



- The Built-in 12V power supply in the user area of the Sol-Ark (Pins 15 and 16) is rated for 100mA (1.2W)
- Transmitter fits inside the user area of the Sol-Ark 8K but can cause interference (sometimes requires placing it outside of the user area)
- TIGO Optimizers are compatible with the Sol-Ark 8K (Do not use the built in 12V Power supply in the Sol-Ark user area to Power the Tigo Optimizer TX transmitter)

Misc. Hardware Recommendations

Disconnect / Transfer Switches: 200A Non-Fused Transfer Switch Model #TC10324R (GE) | 200A Fused Transfer Switch Model #DG224NRK (Eaton)

PV Fuses: 15A PV MC4 in-line fuse holder (ZOOKOTO or DPJ)

Electrical Panel: Any appropriately rated panel for your loads (Check local hardware stores for recommendations)

Powering-Up and Testing the Sol-Ark 8K

Check the voltage on each PV input circuit

A. Should be no higher than 500Voc Temp. corrected

A B. DO NOT connect PV+ OR PV- to GND

C. Verify polarity (backward polarity shows 0V)

Check Grid Input Voltage

- A. Measure L1 to Neutral and L2 to Neutral. Ensure 120Vac
- B. Measure L1 and L2Ensure 240Vac
- C. Check Neutral and Ground are ~0V AC
- D. Verify L1 voltage on AC in/out is 0Vac with the main L1 connection in the panel Same for L2

Check Battery Voltage

- A. Turn on the battery switch (if using a Lithium battery)
- B. Turn on the built-in battery disconnect in the user area
- C. The voltage should be 45Vdc-60Vdc

Provide Power to Sol-Ark

- A. Turn on Grid Breaker and Load Breaker
- B. Turn PV disconnect switch to the "ON" position
- C. Press the ON/OFF Button on the front, and the blue light should turn on

Indicator LED's

DC

- A. Green = DC Solar Panels are producing
- B. Off = Solar Panels are not producing

AC

- A. Green = Grid (or Gen or AC Coupled) is Connected
- B. Off = grid is not Connected

Normal

- A. Green = Sol-Ark 8K is working properly
- B. Off = Sol-Ark 8K is not working properly

Alarm

- A. Red = Alarm, check the alarms menu
- B. Off = No alarms



Turn ON with one of three sources of power:1) PV2) Grid3) ON/OFF Battery

Power Cycle Sequence

1. Turn on the Built-In battery disconnect

2. Make sure that Sol-Ark 8K is properly connected to the batteries, panels, grid, etc. (see system wiring diagram).

3. Turn on grid power breakers.

4. Press the power button on the front of the unit.

5. Make sure Solar panel inputs are not connected to Ground, then Turn on DC disconnect switch.

6. Turn on load breakers.

7. Reverse the steps to turn off





Wi-Fi / Internet Connection

Remote Monitoring Setup

Ethernet Dongle

- A. Open the dongle enclosure and thread the ethernet cable through the hole and plug into the RJ45 port
- B. Reassemble the dongle housing and plug dongle into Sol-Ark and secure with screws
 - If all is well, you will see solid red and green lights
- C. Register the dongle via the app or www.mysol-ark.com

Wi-Fi (Via Cell Phone or computer)

- A. Plug Wi-Fi dongle into Sol-Ark
- B. Using your device look for an "EAP" network containing the last 5 digits of the dongle S/N
- C. Password: 12345678
- D. Follow the instructions in the upcoming pages



You can access PowerView on a computer with the following link: <u>http://www.mysol-ark.com</u>



Download PV Pro App



iPhone: (Will only show up as PV Pro) https://apps.apple.com/lk/app/powe rview-pro/id1247121391





Android https://play.google.com/store/apps/ details?id=com.elinter.app.powervie w&hl=en_US&gl=US



Attention Installers

If you plan to add an install to your installer account for monitoring multiple installs, you must first make the plant under the **customer's** account.

Once created, the customer can share the plant, with **Manager permissions**, to the installer via the app ("..." under My Plants) or webpage (press the "..." next to the plant name in Power View).



PV Pro App





Create an Account and Sign In







Add a Plant





Connect the System to the Internet



Start Monitoring The Data



IP Address Setup Instructions (PC or Smart Phone)

Please Note that this method only achieves internet connectivity. For registration and account management please use the app and/or <u>WWW.mysol-ark.com</u>

Connect to the Dongle Network

A. Settings \rightarrow Wi-Fi \rightarrow Select the Network with EAP- ##### (The last 5 digits of your SN number)





Password: 12345678

***Disclaimer*:** The Wi-Fi dongle does not have internet; You still need to be connected to the dongle for this process.

Login to Web Portal using ANY Search Browser

A. Open Google or Safari \rightarrow type in the

search bar: 10.10.10.1

- B. Scroll Down to "Wi-Fi Connection"
- C. Press "Scan" to search local networks

Select Your HOME Network

- A. Find the home network
- B. Enter personal Wi-Fi Password
- C. DO NOT SELECT DONGLE NETWORK
- D. Select "Connect"

Wlan Connect	ion Wi-	FI ~
Wi-Fi SSID:	wifi_test	
Connection Status:		
Using the f	ollowing static IP addre	SS
Address:	0.0.0	
Netmask:	0.0.0.0	
Gateway:	0.0.0	
		Save Scan
TP-LINK_735E		(î)
EAP-70162		(
EAP-40006		(
EAP-40004		()
SolArk		(
DIRECT-1d-HP	M477 LaserJet	-
CableWiFi		(
SpectrumWiFi	Plus	-
EAP-70070		(
FreeMotion-2G		-

		Device Inform	ation
Cloud Inform	nation	Serial Number:	E47011970018
Connection	Connect Fail	Register Key:	WSMQCERXVXLRY
Status:		Hardware Version:	AEW2-0001-02
Firmware Up	grade	Software Version:	4710119826R
Choose File No	o file chosen		
		Cloud Inform	ation
	Upgrade	Connection	Connect Fail
Wlan Connec	stion Wi-Fi V	orarao.	
Wi-Fi SSID:	wifi_test	Eirmwore Line	rada
Connection Status:	Connect Fail	Change Elle No	fla abaaaa
Using the	following static IP address	Choose File No	nie chosen
delegence			
daress:	0.0.0.0		
letmask:	0.0.0.0		
letmask: letway:	0.0.0.0	Wlan Connectio	n Wi-Fi
letmask: Sateway:	0.0.0.0 0.0.0.0 0.0.0.0 Save Scan	Wlan Connectio Wi-Fi SSID:	n [WI-Fi wifi_test

© 10.10.10.1

33 :

HS

Disclaimer Connecting the dongle via the IP address only connects the dongle to the internet

YOU MUST STILL CREATE AN ACCOUNT VIA THE POWER VIEW APP

Save Your Information

Connection Status:	Connect Fail	
Firmware Up	grade	
Choose File No	file chosen	
		_
		Upgrade
Wlan Connec	tion	Wi-Fi ~
Wi-Fi SSID:	wifi_test	
Connection Status:	Connect Fail	
Using the f	ollowing static IP ad	dress
Address:	0.0.0.0	
Netmask:	0.0.0.0	
Gateway:	0.0.0	
		Save Scan

If Successful you should see a Red and Green light on the Dongle showing a successful connection.

Red LED: Connected to Sol-Ark and has power.

Green LED: Connected to Internet and Server

Flashing Green LED: Connected to router but not server (usually a VPN or firewall issue)





GUI Screens

Main Menus

Solar Today=53KWH	Total=559.8KWH	Solar	Grid	INV	USP LD	Batt	System Setup 察	1/25/2021 03:05:27 PM Mon.
	55.2V	3882W	-3081W 60.0Hz	3702W 60.0Hz	621W 122V	-26W	Basic Setup	System Alarms
	\checkmark	L1:263V	126V	122V	oW	54.70V		Only w/ BMS Lithium Mode
	\checkmark	5.4A	HM: -786W	15.2A	121V	-0.53A		
		1398W	LD:-1876W	1857W	640W	25.0C	Battery Setup	Li-Batt Info
8.00 -2.60	3.00 -2.40	L2: 264V	122V	121V	Gen	TEMP		Sol-Ark 5k/8k/12k-P
		9.5A	HM:1142W	14.8A	4V	DC: 55.0C	Grid Setup	- ID: ######### SD - COMM: ####
		2484W	LD:1205W	1845W	0.0H2 0W	AC:49.7C		- MCU: Ver####
System Alarms	1/25/2021 03:05:27 PM Mon.	0.00 V	0.00 A	0.0 C	0% 0	Ah		
Alarms Code	Occurred	0.0 V	0.0 V	0A	0A	0x00 0x00		
F13 Grid_Mode_changed F13 Grid_Mode_changed	2021-01-13 11:22 2021-01-13 11:20	1. 0.00V 0.0 2. 0.00V 0.0 3. 0.00V 0.0 4. 0.00V 0.0 5. 0.00V 0.0 5. 0.00V 0.0 7. 0.00V 0.0 7. 0.00V 0.0 9. 0.00V 0.0 10. 0.00V 0.0 11. 0.00V 0.0 13. 0.00V 0.0	Only w. 004 0.00 0.0% 005 0.00 0.0% 004 0.00 0.0%	/ BMS Lith 0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.	No.04 No.04 V 0.04 V 0.04	2 0000 0000 0000 0000 0000 0000 0000 0	_	

Basic Setup

Basic Setup	Basic Setup	Basic Setup
Display Time Advanced Factory Reset Parallel	Display Time Advanced Factory Reset Parallel	Display Time Advanced Factory Reset Parallel
Brightness Brightness	YearMonthDayAM/PM20211026	ARC parameters Osolar Arc Fault ON Clear Arc_Fault Osolog O45000 O4500 O450 O45
Auto Dim 📈 6005	Hour Minute Second	Gen Limit Power 9000W 000050 000390 Load Limit Power 8000W 238094
	Season1 Season 2 Season 3 Seasons Start M-D 1 - 1 4 - 1 8 - 1	Grid peak-shaving Power 8000W
CANCELOK	CANCEL OK End M-D 4 - 1 8 - 1 12 - 1	CANCEL OK UPS Time Oms
Basic Setup	Basic Setup	<u></u>
Basic Setup Display Time Advanced Factory Reset Parallel	Basic Setup Display Time Advanced Factory Reset Parallel	
Basic Setup Display Time Advanced Factory Reset Parallel Factory Reset System selfcheck	Basic Setup Display Time Advanced Factory Reset Parallel Parallel Master Modbus SN 00 Phase A Slave Slave Phase B	
Basic Setup Display Time Advanced Factory Reset Parallel Factory Reset System selfcheck Lock out all changes Test Mode	Basic Setup Display Time Advanced Factory Reset Parallel Master Modbus SN OD Phase A Phase B Meter > Grid Meter > Load Phase C Phase C	
Basic Setup Display Time Advanced Factory Reset Parallel Factory Reset System selfcheck Lock out all changes Test Mode Lock Grid Charging & Limited	Basic Setup Display Time Advanced Factory Reset Parallel Parallel Master Modbus SN 00 Phase A Parallel Slave Phase B Phase B Meter > Grid Meter > Load Phase C Meter Select Meter Select No Meter	-

Battery Setup

Batt Setup	Batt Setup	Batt Setup
Batt Charge Discharge Smart Load	Batt Charge Discharge Smart Load	Batt Charge Discharge Smart Load
Batt Capacity 200Ah Use Batt V Charged	StartV 49.0V 49.0V Float V 54.8V	Shutdown 46.0V 20% Batt Resistance 25mOhms
Max A Charge 100A 🗸 Use Batt % Charged	Start% 30% Absorbtion V 55.5V	Low Batt 47.5V 30% Batt Charge 99.0%
Max A Discharge 185A No Battery	A 40A 100A Equalization V 55.5V	Restart 52.0V 40%
TEMPCO -0mV/C/Cell BMS Lithium Batt 00	Gen Charge Grid Charge	Batt Empty V 47.0V BMS_Err_Stop
🖌 Activate Battery	Generator Excercise Cycle Day & Time>> Mon 08 :00 20min	
CANCELOK	Gen Force CANCEL OK	CANCELOK
Batt Setup		
Batt Charge Discharge Smart Load		
Use gen input as load output For AC Coupled Input to Gen		
On Grid always on High Frz 62.00Hz		
Smart Load OFF Batt AC couple on load side Smart Load ON Batt 90% Solar Power(W) CANCEL		

Grid Setup

Grid Param Limiter Sell Control Grid Input FreqVolt PowFac Grid Sell 08000 Time Power(W) Batt Charge Sell Limited Power to Home 05:00AM 2000 50%	Grid P. ran Limite Imite Imite <th>Grid Param Limiter Sell Control General Standard Grid Reconnect Time UL1741 & IEEE1547 GEN connect to Grid Input UL1741SA Zero Export Power Zero Export Power Load First Load First CANCEL</th>	Grid Param Limiter Sell Control General Standard Grid Reconnect Time UL1741 & IEEE1547 GEN connect to Grid Input UL1741SA Zero Export Power Zero Export Power Load First Load First CANCEL
Grid Param Limiter Sell Control Grid Input FreqVolt PowFac Relay Grid Frequency 50Hz 0 60Hz Grid Type Grid Vol Low 220V Single Phase Grid Hz High 120/240V Split Phase Grid Hz Low 120/208V 3 Phase CANCEL	Grid Param Limiter Sell Control Grid Input FreqVolt PowFac L/HVRT L/HFRT HV2: 252.0V 0.165 HF2:65.00Hz 0.165 LV1: 184.8V 205 LF1:58.50Hz 2995 LV2: 147.0V 105 LF2:57.00Hz 0.165 LV3: 105.0V 0.165 OK	Grid Param Limiter Sell Control Grid Input FreqVolt PowFac Q(V) FW VW V1:216.0V Q1: 0.44 Fstart.60.50Hz Vtstart.254.4V V2:225.6V Q2: 0.00 Fstop.62.00Hz RT:5.0s RT:10s V4:264.0V Q4: 0.44 Normal Ramp rate 10.0%/s CANCEL OK OK



Programming Guide



Main Screens (Touchscreen)



Detailed Volts View

- Top row = Total power for column
- Middle Row = Line 1/PV1 voltage, Amps, and Watts
 (note: PV Voltage not to exceed 500V)
- Bottom Row = Line 2/PV2 voltage, Amps, and Watts

 (note: PV Voltage not to exceed 500V)
- Batt Temperature will show -20°C if the temperature sensor is not connected. Batt SOC % = % batteries are charged
- DC Temp = Temperature of DC conversion electronics
 - \circ Batt \rightarrow AC
 - \circ PV \rightarrow Batt
 - \circ AC \rightarrow Batt
- AC Temp = Temperature of AC conversion electronics
 - Batt → AC
 - \circ PV \rightarrow AC
- Grid Column
 - If selling to the Grid, Grid Watts = negative
 - If buying from the Grid, Grid Watts = positive
 - HM = power detected by the external current sensors on the entire home L1 & L2
 - LD = power detected using internal sensors on AC grid in/out breaker

PV Graphical View

- A. Displays power production over time for the PV array
- B. Use up/down buttons to navigate between days
- C. Month view, Year view, and Total view

Solar	Grid	INV	USP LD	Batt
3882W	-3081W 60.0Hz	3702W 60.0Hz	621W 122V	-26W
L1: 263V	126V	122V	oW	54.70V
5.4A	HM: -786W	15.2A	121V	-0.53A
1398W	LD:-1876W	1857W	640W	25.0C
L2: 264V	122V	121V	Gen	ТЕМР
9.5A	HM:1142W	14.8A	4V	DC: 55.0C
2484W	LD:1205W	1845W	0.0H2 0W	AC:49.7C



Note: Reversed Grid Watt values may indicate incorrectly installed current sensors (reversed polarity). See Page 34.

Grid Graphical View

- A. Displays power drawn from and sold to the grid over time
- B. Bars above the line indicate power bought from the grid
- C. Bars below the line indicate power sold back to the grid

This view can help determine when the peak power is used in the Home and for Time of Use programing

System Setup Menu

- A. ID = LCD serial #. Support uses the Wi-Fi serial #.
- B. COMM = LCD software version
- C. MCU = Inverter software version

Basic Setup

Display

- A. Brightness adjustment
- B. Auto dim (must be enabled for the warranty to cover LCD screen)
- C. Enable/disable BEEP

Time

- A. Set date and time for the system
- B. Set up to 3 seasons for Time of Use to follow

Gen Peak Shaving (Gen Limit Power)

Set the threshold at which the Sol-Ark will contribute to the generator to prevent large loads overloading the generator.

Load Limit Power

Set the total AC Output of the Sol-Ark, excess power will be curtailed. The default value is always the Maximum output of the inverter.

Grid Peak Shaving

Set the Sol-Ark's threshold to begin contributing power to keep the power drawn from the grid below the threshold.

CT Ratio

Set the CT ratio; Default value is 2000/1. **DO NOT** change this value unless you speak with support, use of 3rd party CT sensors require our permission to not void warranty.

UPS Time

Set the delay to Sol-Ark's UPS transfer time; When set to Oms, the UPS transfer time will be 4ms.

Parallel (connecting multiple systems)

This tab does not apply to the Sol-Ark 8K, as it is a single-system solution.

System Setup 😴	1/25/2021 03:05:27 PWI Mon.
Basic Setup	System Alarms
Battery Setu	p
Grid Setup	Sol-Ark 8k/12k-P - ID: ########## SD - COMM: #### - MCU: Ver####
Basic Setup	
Display Time	Advanced Factory Reset Parallel
Brightness	Беер
Auto Dim 😾 60	005
CAN	

Basic Setup	•						
Display	Time	Advanced	Factory Reset	Parallel			
Solar /	Arc Fault	ON C	Clear Arc_Fault	ARC parameters 030000 045000 000400			
	Ger	n Limit Powe	er 9000W	000050			
	Load	l Limit Powe	er 9000W	000055 238094			
Grid p	Grid peak-shaving Power 9000W						
Auto c	letect Ho	me Limit Se	nsors CT rati	o 2000			
	CANCEL	ОК	UPS Tim	e Oms			

Display	Time	Advanced	Factory Re	eset P	arallel	
Parallel	Mast	er		_	Phase A	
Paraller	🔘 Slave	Modbus	5N 00) Phase B	
Meter > C	Frid	Meter > Lo	ad	C)Phase C	
Meter Select	ρ	Meter Select				
No Meter		No Meter				
					_	

System Alarms

A. Lists all recorded System alarms in chronological order

Battery Setup

Batt

Batt Capacity: enter the size of the battery bank connected to the system. Series = add Voltage | Parallel = add Amp-Hours

Max A Charge: set the max charge rate for the batteries (This also sets $PV \rightarrow Battery$ charge rate)



Suggest 20%-30% of battery capacity for lead-acid

Max A discharge: set max discharge for battery bank (In off-grid mode, the battery bank will discharge 120% of this value for 10 seconds before the inverter shuts down to prevent battery damage)

TEMPCO: Temperature coefficient used in conjunction with the batt temp sensor to adjust optimal voltages for leadacid batteries

Use Batt V Charged: displays battery charge in terms of voltage

Use Batt % Charged: Battery voltage can be misleading for determining the % Charged. So, we use algorithms measuring power in and out to measure a true value for % Charged. It compensates for aging batteries also.

Charge

Float V: Set value appropriate for the batteries connected to the system

Absorption V: Set value suitable for the batteries connected to the system

- Absorption will stop at 2% of the capacity of the battery bank and drop to float
- Ex: 400Ah battery would be 8A

Equalization V: Set value appropriate for the batteries in use.

Days: the period between equalization cycles

Hours: period taken to equalize batteries



Note if Hours = 0 system will not equalize the batteries

Gen Charge: uses the gen input of the system to charge the battery bank from an attached generator.

Start V: voltage at which system will AutoStart a connected generator to charge the battery bank

Start percentage: Percent S.O.C at which system will AutoStart a corresponding generator to charge the battery bank

A: Charge rate from the attached Generator in Amps (DC)



Size this value according to the generator size

Grid Charge: uses Grid input to charge batteries from grid or generator

Syste	m Alarms	1/25/2021 03:05:27 PM Mon		
Alarn	ns Code	Occurred		
F13	Grid_Mode_changed	2021-01-13 11:22		
F13	Grid_Mode_changed	2021-01-13 11:20		

Batt Setup					
Batt Charge I	Discharge	Smart Load			
Batt Capacity	200Ah	Use Bat	t V Charged		
Max A Charge	100A	🗸 Use Bat	t % Charged		
Max A Discharge	185A	No Battery			
ТЕМРСО -0)mV/C/Cell	BMS Lithium Batt 00			
		🗸 Activate	Battery		
CAI	NCEL	ОК			

Batt Se	etup							
Batt	Charge	Discharge	S	mart Load				
]				
StartV	49.0V	49.0V		Float V	54.8V			
Start%	6 30%	30%		Absorbtion V	55.5V			
A	40A	100A		Equalization V	55.5V			
Ge	n Charge	Grid Charge	e	30 Days	0.0 Hours			
Generat	Generator Excercise Cycle Day & Time>> Mon 08 :00 20min							
G	en Force	CANCEL		ОК				

Gen Exercise Cycle (Day & Time): Set a weekly Gen exercise schedule. (Day of the week/Time/Duration Length) Gen **must** have two-wire start connected to Sol-Ark. To disable the exercise, set the duration length to 0 min.

Discharge

Shutdown V: battery voltage at which the inverter will shut down (battery symbol on the home screen will turn red)

Low Batt: Low battery voltage (battery symbol on the home screen will turn yellow)

Restart: battery voltage at which AC output will resume

Batt Resistance: used in % SOC batt calculations

Batt Charge Efficiency: used in % SOC batt calculations

Batt Empty V: sets reserve capacity and improves % SOC calculations. It is not Batt_I adjusted



(Recommendations: 45V for AGMs, 48V for Lithium Iron Phosphate)

Smart Load (Gen Breaker)

- A. This mode utilizes the Gen input connection as an output that only receives power when the battery exceeds a user-programmable threshold.
- B. Enable "Use gen input as load output" to power high power loads such as a water heater, irrigation pump, AC unit, pool pump, etc.

Smart Load OFF Batt

Battery voltage at which the Gen Load will stop receiving power

Smart Load ON Batt

Battery voltage at which the Gen Load will start receiving power



Using Gen load for a water heater, we recommend that only one leg (120V) be connected to the bottom element. This significantly reduces the power consumption of the water heater while retaining core functionality (it will heat water, only slower).



Gen Load is limited to 50A at 240V (Do not exceed!)

Solar Watts is for on Grid

A. The system waits to turn on smart load until enough PV power is produced (when on grid)

AC Coupling Settings ("For AC Coupled Input")

- A. To use the Gen input breaker as an AC coupled input, check the "For AC Coupled Input" box (this feature will also work with "Grid-Tied" Inverters)
- B. The meaning of Smart Load OFF Batt and Smart Load ON Batt change in this mode

Smart Load OFF Batt: The SOC at which the AC coupled inverter(s) are shut down when in off-grid mode



Smart Load ON Batt: The SOC at which the AC coupled inverter(s) are turned on when in off-grid mode



60%-80% recommended

90% recommended

Batt Se	tup						
Batt	Charge Discharge	Smart Load					
Shutdow Low Batt	n 46.0V 20% 47.5V 30%	Batt Resistance Batt Charge Efficiancy 99.0%					
Batt Emp	ty V 47.0V	BMS_Err_Stop					
CANCEL							

Batt S	etup		
Batt	Charge	Discharge	Smart Load
	Use gen inpu	it as load output	For AC Coupled Input to Gen
	On Grid	always on	High Frz 62.00Hz
Smart L 51.0V Smart L 54.0V	oad OFF Batt 80% oad ON Batt 90%		AC couple on load side
Solar Po 500W	ower(W)		CANCEL OK

When On-Grid, the AC-coupled inverter will always be on, and the will sell any extra power back to the grid. **AC Coupled PV Arrays will not work WITHOUT grid sell enabled (while grid is available).**

To use the LOAD breaker for AC coupling grid tied inverter(s)

- i. You must select "For Micro Inverter Input"
- ii. The Gen Breaker is not used (even though the GEN breaker is not physically being used for this mode, AC coupling on the LOAD breaker prevents the use of the GEN breaker)
- iii. Wire as show in the preceding example diagram labeled "Load side AC coupling example"



Some load-side AC coupling installs will require a line side tap instead of the 50A breaker shown in the example diagram

Grid Setup

Limiter

Grid Sell: maximum watts sold to grid

Limited To Home: Limits power produced by the system to match the demand of the Home

Limited To Load: Limits power produced by the system to match the demand of connected loads

Time Of Use: Control battery behavior w/ grid available

Time: When the System will sell batt/PV power to the Grid or Home

Power(W): Max watts called from the battery only at each time

Batt: The battery voltage or % at which the system will limit selling to the Grid or Home from the battery. The system will drain the battery until reaching that percent/voltage.

Charge: Enables grid/gen charging up to the voltage or percentage specified on the line during a selected period. PV will always charge 100%. If using a generator, select the charge box for the times that may need the generator, and the Gen will charge the battery to the voltage of percentage specified in the "Batt" column.

Sell: The sell check box allows the battery to be discharged for grid sell-back for that time slot



Note: If you need the batteries to never charge from the grid, **uncheck** the "Grid Charge" box under the charge tab of the battery menu.

Sell Control

General Standard: uses Protect Parameters in table

UL 1741 & IEEE1547: Enables sell compliant functionality

UL1741SA: Enables wider Freq, Voltage, and Power Factor

GEN connect to Grid Input: Enable if Generator connects to the AC Grid breaker

Zero Export Power: Power drawn from the grid at all times

miter	Sell Control	Grid Input	FreqVolt	PowFac	Relay
	Seneral Standard	Grid F	Reconnect Tir	me 30	0s
	JL1741 & IEEE154	7	GEN	connect to G	irid Input
	JL1741SA		Zero Expo	rt Power 20	W
			Batt Fi	rst	Load First
			ANCEL		ок

Grid Param									
Limiter Sell Co	ntrol G	rid Input	F	reqVolt	PowFa	с	Rela	y	
	2000	Time		Power(W)	Batt	Ch	arge	Se	ell
Grid Sell 08	3000	01:00A	M	2000	50%				
Limited Powe	05:00A	Μ	2000	50%					
Limited Powe	09:00A	Μ	2000	100%					
		01:00PI	М	2000	100%				
Time of Use	05:00P	Μ	2000	50%					
CANCEL	ОК	09:00P	М	2000	50%				

Grid Input

Grid Frequency: Select the Grid Frequency connection Grid Type:

- 220V Single Phase (Call us before using)
- 120/240V Split Phase (North America)
- 120/208V 3 Phase

Protect Parameters: (when Settings when the system will connect/disconnect from the grid. UL 1741 & IEEE1547 do not use these parameters.

We recommend widening the frequency range when connecting a generator to the grid breaker (55-65Hz)





If 120/208V, the L1 and L2 are phase specific. So, you may have to swap Grid L1 L2 for 208V applications.

Inverter power cycle is required each time the input/output voltage is changed

Selecting Power Mode

Sol-Ark 8K will simultaneously use various power sources available to meet loads demand. The following power modes allow the user to determine the power sources available to the Sol-Ark 8K.

Limited Load / Self Consumption

- A. Sol-Ark will only power loads connected to it.
- B. It will not produce more power than the connected loads require.
- C. This mode will neither sell back to the Home nor Grid.

Limited To Home (Zero-Metering)

Main Menu \rightarrow System Settings \rightarrow Grid Setup \rightarrow Limiter \rightarrow Limited to Home

- A. Pushes power to the whole Home without selling back any excess to the grid (no net metering agreement required)
- B. This mode requires the use of the limiter sensors
- C. Power source priority is the same as Grid Sell Back

Grid Sell

Main Menu \rightarrow System Settings \rightarrow Grid Setup \rightarrow Limiter \rightarrow Grid Sell

A. This mode allows Sol-Ark 8K to sell back any excess power produced by the solar panels to the grid. **Power source priority:**

1. Solar Panels | 2. Grid | 3. Generator (Manual) | 4. Batteries (until reaching programmable % discharge)

Time Of Use (using batteries during peak power times)

 $\mathsf{Main}\;\mathsf{Menu}\; \textbf{\rightarrow}\;\mathsf{System}\;\mathsf{Settings}\; \textbf{\rightarrow}\;\mathsf{Grid}\;\mathsf{Setup}\; \textbf{\rightarrow}\;\mathsf{Limiter}\; \textbf{\rightarrow}\;\mathsf{Time}\;\mathsf{Of}\;\mathsf{Use}$

A. Use the batteries to reduce power consumption from the grid during a user programable peak pricing time.

Power source priority:

1. Solar Panels | 2. Batteries (programmable % discharge) | 3. Grid (control when Grid charges) | 4. Generator

Grid Param								
Limiter Sell C	Control G	rid Input	F	reqVolt	PowFa	c Rel	ay	
		Time		Power(W)	Batt	Charge	S	ell
	Grid Sell 08000			2000	49.0V			
Limited Po	05:00A	М	2000	49.0V				
Limited Po	Limited Power to Load			2000	49.0V			/
				2000	49.0V		~	7
Time of Us	05:00P	М	2000	49.0V		$\overline{}$	7	
CANCEL	ОК	09:00P	М	2000	49.0V			
	L]							

Simultaneously select Grid Sell and Limited to Home

Load (light bulb) icon on the home screen now includes both the load breaker power and the home's consumption.

FreqVolt (UL 1741SA must be enabled in "Sell Control" tab)

Puerto Rico Grid Compliance Settings:

Grid Param			
Limiter Sell Control	Grid Inpu	ut FreqVolt Po	owFac
✓ L/HVRT		✓L/HFRT	
HV2: 288.0V 0.16	s	HF2:61.50Hz	105
HV1: 264.0V 15		HF1: 60.50Hz	3005
LV1: 211.2V 25		LF1: 59.20Hz	300S
LV2: 144.0V 15		LF2: 57.50Hz	105
LV3: 108.0V 0.16	s		
CANCEL			ок

Kauai Grid Compliance Settings:

Grid Param					Grid Param			
Limiter Sell Co	ontrol Grid In	put F	reqVolt Po	wFac	Limiter Sell C	ontrol Grid Inp	but	FreqVolt
		\checkmark	L/HFRT		$\sqrt{Q(V)}$			V FW
HV2: 288.0V	0.165		HF2: 64.00Hz	0.165	V1: 225.6V	Q1: 0.44		Fstart: 60.10H
HV1:264.0V	55		HF1: 63.00Hz	205	V2: 232.8V	Q2: 0.00		Fstop: 62.40H
LV1: 204.0V	205		_F1: 57.00Hz	205	V3: 247.2V	Q3: 0.00		RT: 0.5s
LV2: 120.0V	0.165		F2: 56.00Hz	0.165	V4: 254.4V	Q4: 0.44		Normal Ramp
LV3: 110.0V	0.165				Response Time	10s		Soft Start Ran
CAN	CEL	-	C	ж	CA	ICEL		

HECO Grid Compliance Settings for O'ahu, Maui, Hawai'i:

Grid Param								
Limiter Sell Control Grid Input FreqVolt PowFac								
			L/HFRT					
HV2: 288.0V	0.165		HF2: 64.00Hz	0.165				
HV1: 264.0V	15		HF1: 63.00Hz	205				
LV1: 211.2V	205		LF1: 57.00Hz	205				
LV2: 168.0V	105		LF2: 56.00Hz	0.165				
LV3: 120.0V	0.165							
CANCEL			0	ĸ				

Grid Param	
Limiter Sell Control Grid Ir	nput FreqVolt PowFac
Q (V)	VW VW
V1: 225.6V Q1: 0.44	Fstart: 60.10Hz Vstart: 254.4V
V2: 232.8V Q2: 0.00	Fstop: 62.40Hz Vstop: 264.0V
V3: 247.2V Q3: 0.00	RT: 0.5s RT: 10s
V4: 254.4V Q4: 0.44	Normal Ramp rate 100.0%/s
Response Time 10s	Soft Start Ramp rate 0.3%/S
CANCEL	ОК

rate 100.0% p rate 0.3%/s OK

HECO Grid Compliance Settings for Lana'I and Moloka'i:

Grid Param			
Limiter Sell Con	trol Grid Inpu	ut FreqVolt Pow	/Fac
L/HVRT		L/HFRT	
HV2: 288.0V	0.165	HF2: 65.00Hz	0.165
HV1: 264.0V	15	HF1: 63.00Hz	205
LV1: 211.2V	205	LF1: 57.00Hz	205
LV2: 168.0V	105	LF2: 56.00Hz	0.165
LV3: 120.0V	0.165	L	
CANCE	L	OH	<

Grid Param				
Limiter Sell Contro	ol Grid Input	FreqVolt	PowFa	с
Q (V)		V FW		vw
V1: 225.6V Q	1: 0.44	Fstart: 60.10Hz	z Vs	tart: 254.4V
V2: 232.8V Q	2: 0.00	Fstop: 62.40Hz	: Vs	top: 264.0V
V3: 247.2V Q	3: 0.00	RT: 0.5s	R	T: 10s
V4: 254.4V Q4	4: 0.44	Normal Ramp	rate 1	00.0%/s
Response Time 10)s	Soft Start Ram	prate C).3%/s
CANCEL			ОК	

PowFac

Power Factor is programmable from 0.8 – 1.0

Limiter Sensor Automatic Setup

Requires Batteries, AC coupled panels must be off while detecting, and does <u>NOT</u> work for 208V installs. If you do not have batteries or are in 208V mode: verify CT sensor placement manually.

- A. Install limiter sensors as previously described (shown in all diagrams as well). Battery and grid connections also required before starting auto-setup.
- B. Navigate to the "Advanced" Tab of the Basic Setup screen (follow the directions below to get there) A. Touch the gear icon \rightarrow Touch the Basic Setup button \rightarrow Select the Advanced tab (see Fig. C)
- C. Select "Auto detect Home Limit Sensors" and press "OK"
- D. Wait for the Sol-Ark to finish its learning process (Sol-Ark will alternate sell back between legs and magnitude automatically determining the correct settings for the sensors)
- E. Verify sensors were correctly configured (see Fig. D) if they are not correct, repeat the learn function



Verifying proper sensor direction:

- Any loads in the home will show a positive HM (+) value in Watts
- Turning on solar panels and enabling Grid Sell should show a negative HM (-) in Watts if you are producing more power than the loads are consuming
- If you turn on limited power to Home mode, then HM: ~0 Watts to zero the meter (system matches the loads to within 99%)



If you installed limiter sensors (CTs) for Limited To Home selling mode, verifying the proper sensor placement and direction is critical. Remove one sensor from the main L1 connection, and the power should drop to 0W.



Off-Grid Install Tips

ol-Ark

Sol-Ark 8K will automatically operate in Off-Grid Mode without the grid (under the same power priority as TOU).

- A. Limiter Sensors are not required for completely Off-Grid installs unless using Grid Peak Shaving with a Gen connected to Grid input breaker.
- B. The Grid input breaker on the Sol-Ark should be used as the Generator input (4-30kW generators) so that you maintain Smart Load output capability when off-grid. Smart Load will allow you to run high-power non-essential appliances (hot water, dehumidifier, heat pump, irrigation pump) on solar power instead of batteries. Therefore, you will use Grid Charge (default) in the Battery Setup/Charge menu.
- C. When off-grid, there is no need for a transfer switch: connect the load output of the Sol-Ark to the whole home.
- D. Do not use Grid Sell or Limited To Home Modes Off-Grid. Only Limited power to load (default).
- E. The Auto Generator start functions as a 2-wire switch (closes the circuit when needing charging)
 - Auto Gen-start will be triggered when the battery voltage or percent reaches the level programmed in the battery setup menu. Then, the generator will continue to charge the batteries until they are about 95% full (this percentage is not programmable) before turning the generator off.
 - ii. When using the Sol-Ark to control a generator, an exercise function will turn on the generator once a week on Monday mornings at 8 AM by default
- F. We recommend changing the "Grid Reconnect Time" under the Sell control tab of the grid setup menu to 30 seconds; otherwise, the Sol-Ark will not charge from the generator until it has been on for at least 5 minutes per the default value of 300 seconds.
- G. Under setup for Grid/Sell Control, select General Standard and "GEN connect to Grid Input." Then go to Grid input to widen the input frequency range to 55-65Hz to work with any frequency generator.
- H. If you would like to use a wind turbine in conjunction with the Sol-Ark 8K, the turbine must have a 48V charge controller with a dump load to prevent overcharging the batteries. Connect the charge controller on the turbine to the battery bank the Sol-Ark is using, and the turbine will help charge the batteries.
- I. Don't forget to set the Battery capacity and reasonable charge rates.

Grid-Tie / No Battery Install Tips

- A. Under Battery setup, select no Battery & disable Activate Battery (or system will beep).
- B. Note: a whole system power cycle is required when changing the battery to no battery settings.
- C. Under Grid Setup, select Grid Sell.
- D. Touch Battery Icon to see the Detailed Volts View to verify your inputs & outputs.

Batt Se	etup			
Batt	Charge	Discharge	Smart Load	
\checkmark	Use gen inpu	it as load output	For AC Coupl	ed Input to Gen
	🗸 On Grid	l always on	High Frz 6	2.00Hz
Smart L 51.0V	oad OFF Batt		AC couple on	load side
Smart L 54.0V	oad ON Batt 90%			
Solar Po 500W	ower(W)			ОК

Batt Se	Batt Setup						
Batt	Charge	Discharge	S	mart Lo	ad		
StartV	49.0V	49.0V	1	Float V		54.8	V
Start%	6 30%	30%	1	Absorb	tion V	55.5	V
А	40A	100A	1	Equaliz	ation V	55.5	V
Ge	n Charge	Grid Charg	e	30 Day	5	0.0	Hours
Generat	or Excercise	Cycle Day & Tim	e>:	Mon	08	:00	20min
G	en Force	CANCEL			ОК		

ball Setup							
Batt Cha	arge	Discha	arge	Smar	t Load		
Batt Capac	Batt Capacity 200Ah				Use Batt V Charged		
Max A Cha	arge	100 <i>A</i>	4		Use Bat	t % C	harged
Max A Dise	charge	185 <i>A</i>	۹.	\checkmark	No Batt	ery	
ТЕМРСО	-(0mV/C	C/Cell		BMS Lit	hium	Batt 00
					Activate	e Batt	ery
	CA	NCEL			OK		
Solar	Gri	id	IN	١V	USP	LD	Batt
Solar 3882W	Gr i	id 1W	IN 370	IV 02W	USP	LD W	Batt -26W
Solar 3882W	Gr i -308 60.0	id 1W Hz	IN 370 60.	IV D2W OHz	USP 621 122	LD W V	Batt -26W
Solar 3882W	Gri -308 60.0	id 1W Hz	IN 370 60. 12	IV 02W 0Hz 2V	USP 6211 122 0W	LD W V	Batt -26W 54.70V
Solar 3882W L1: 263V 5.4A	Gri -308 60.0 126 HM: -7	id 1W Hz 5V 786W	IN 37(60. 12 15	1V 02W 0Hz 2V .2A	USP 6211 122 0W 121	LD W V V	Batt -26W 54.70V -0.53A
Solar 3882W L1: 263V 5.4A 1398W	Gri -308 60.0 126 HM: -7 LD:-18	id 1W Hz 5V 786W 876W	370 60. 12 15 185	1V D2W 0Hz 22V .2A 57W	USP 621 122 0W 121 640	LD W V V W	Batt -26W 54.70V -0.53A 25.0C
Solar 3882W L1: 263V 5.4A 1398W L2: 264V	Gri -308 60.0 126 HM: -7 LD:-18 122	id 1W Hz 5V 786W 876W 2V	370 60. 12 15 185	1V 0Hz 22V .2A 57W	USP 6211 122 0W 121 640 Ge	LD W V V W	Batt -26W 54.70V -0.53A 25.0C TEMP
Solar 3882W L1: 263V 5.4A 1398W L2: 264V 9.5A	Gri -308 60.0 126 HM: -7 LD:-18 122 HM:11	id 1W Hz 5V 786W 876W 2V 42W	IN 370 60. 12 15 185 12 12	1V 02W 0Hz 22V .2A 57W 11V .8A	USP 6211 122 0W 121 640 Ge	LD V V W	Batt -26W 54.70V -0.53A 25.0C TEMP DC: 55.0C



Battery Charging Information

4-Stage Charging

The MPPT has a 4-stage battery charging algorithm for rapid, efficient, and safe battery charging. The figure below shows the stage sequence.

Bulk Charge Stage

In the Bulk Charge stage, the battery is not at a 100% state of charge and has not yet reached the Absorption voltage setpoint. The controller will deliver 100% of available solar power to recharge the battery.



Absorption Stage

When the battery has reached the absorption voltage setpoint, we use constant-voltage

regulation to maintain battery voltage at the absorption setpoint, preventing heating and excessive battery gassing. The battery is allowed to come to a full state of charge at the absorption voltage setpoint. Absorption lasts until batteries charge at 2% of the programmed Ah size.

Float Stage

After the Absorption stage charges the battery fully, the MPPT reduces the battery voltage to the float voltage setpoint. If batts have 100% charge, there can be no more chemical reactions, and all the charging current turns into heat and gassing. The float stage provides a meager rate of maintenance charging while reducing the heating and gassing of a fully charged battery. The purpose of float is to protect the battery from long-term overcharge.

Battery Charging Setpoint Examples (48V)

Battery Type	Absorption Stage	Float Stage	Equalize Stage (every 30 days 3hr)	
AGM / PCC	14.4v (57.6v)	13.5v (53.6v)	14.4v (57.6v)	Default
Gel	14.1v (56.4v)	13.5v (54.0v)		
Wet	14.7v (59.0v)	13.7v (55.0V)	14.7v (59.0v)]
Lithium	14.1v (54.6v)	13.2v (54.3v)	14.1v (54.6v)]



- Batteries in series: ADD VOLTAGES
- Batteries in parallel: ADD AMP-HOURS

Calculating Battery Bank's Amp-Hours (PCC 230)

Battery	Voltage /	Amp Hours /	Total Amp	Max Charge/
Count	Battery	Battery	Hours @48V	Discharge Amp
4	12V	230Ah	230Ah	100A
8	12V	230Ah	460Ah	185A
12	12V	230Ah	690Ah	185A
16	12V	230Ah	920Ah	185A

Sol-Ark PCC-230 Battery

Batt Capacity: 230Ah x #Parallel Batteries (1 parallel = 4 Batt in series, 2 = 8 Batt, 3 = 12 Batt, 4 = 16 Batt) Max A Charge: 100A x #Parallel Batteries Max A Discharge: 100A x #Parallel Batteries Max A Grid Charge: 50A x #Parallel Batteries TEMPCO: -5mV/C/Cell Float V: 53.6V Absorption V: 57.6V Equalization V: 57.6V **Equalization Days: 30 Equalization Duration: 3 Hours** Recommended Shutdown V / Percentage: 47.0V & 20% Recommended Low Batt V / Percentage: 47.5V & 35% Recommended Restart V / Percentage: 52.0V & 50% Battery Resistance: 35mOhms (8 Batt) or 25mOhms (16 Batt) Battery Charge Efficiency: 99% Battery Empty Voltage: 45V

Generation 2 Fortress Battery-eVault18.5

Batt Capacity: 360Ah x #Parallel Batteries Max A Charge: 150A (100A for life) x #Parallel Batteries Max A Discharge: 160A x #Parallel Batteries Max A Grid Charge: 100A x #Parallel Batteries TEMPCO: 0mV/C/Cell BMS Lithium Batt: 04 Float V: 54.2V Absorption V: 54.4V Equalization V: 55.5V **Equalization Days: 30** Equalization Duration: 1 Hours (tops off battery) Recommended Shutdown V / Percentage: 51.3V & 20% Recommended Low Batt V / Percentage: 51.7V & 30% Recommended Restart V / Percentage: 51.9V & 40% Battery Resistance: 5mOhms Battery Charge Efficiency: 99% Battery Empty Voltage: 46V Simpliphi Power: PHI 3.8 Battery 48V Batt Capacity: 75Ah x # Batt Max A Charge: 37.5A x # Batt (20A for better lifespan) Max A Discharge: 37.5A x # Batt (34A for better lifespan) Max A Grid Charge: 20A x # Batt TEMPCO: 0mV/C/Cell **BMS Lithium Batt: Not Selected** Float V: 55.6V Absorption V: 56V Equalization V: 56V Equalization Days: 30 Equalization Duration: 2 Hours (tops off battery) Recommended Shutdown V / Percentage: 50.2V & 20% Recommended Low Batt V / Percentage: 50.6V & 30% Recommended Restart V / Percentage: 51.0V & 40% Battery Resistance: 24mOhms ÷ (battery Count) Battery Charge Efficiency: 99% Battery Empty Voltage: 46V

Time	Watts	SOC	GridCharge
1:00AM	1500*Par_Batts	70%	
5:00AM	1500*Par_Batts	70%	
9:00AM	1500*Par_Batts	70%	
1:00PM	1500*Par_Batts	100%	
4:00PM	1500*Par_Batts	70%	
9:00PM	1500*Par_Batts	70%	

These settings will charge the batteries off solar only. Discharge the batteries down to a maximum of 70% full.

Limited To Home mode will not sell to the grid from the batteries (only the home will use battery power). The 100% time slot is to ensure that the batteries are properly cycled each day.

Time	Watts	SOC	GridCharge
1:00AM	6000*Par_Batts	40%	
5:00AM	6000*Par_Batts	40%	
9:00AM	6000*Par_Batts	40%	
1:00PM	6000*Par_Batts	40%	
5:00PM	6000*Par_Batts	40%	
9:00PM	6000*Par_Batts	40%	

These settings will charge the batteries off solar only. Discharge the batteries down to a maximum of 40% full.

Limited To Home mode will not sell to the grid from the batteries (only the home will use battery power).

Time	Watts	SOC	GridCharge
1:00AM	1000*Batts	40%	
5:00AM	1000*Batts	40%	
9:00AM	1000*Batts	40%	
1:00PM	1000*Batts	40%	
5:00PM	1000*Batts	40%	
9:00PM	1000*Batts	40%	

These settings will charge the batteries off solar only. Discharge the batteries down to a maximum of 40% full.

Limited To Home mode will not sell to the grid from the batteries (only the home will use battery power).

Blue Ion 2.0 Battery

Batt Capacity: 40Ah x #Parallel Batteries (4 Parallel = 160Ah, 6 = 240Ah, 8 = 320Ah) Max A Charge: 160A w/ 4 Batteries, 185A w/ 6+ Max A Discharge: 160A w/ 4 Batteries, 185A w/ 6+ Max A Grid Charge: 160A w/ 4 Batteries, 185A w/ 6+ TEMPCO: 0mV/C/Cell BMS Lithium Batt: 03 (eGauge) / 00 (Namaka Box) Float V: 55.2V Absorption V: 55.2V Equalization V: 55.2V Equalization Days: 30 Equalization Duration: 1 Hours (tops off battery) Recommended Shutdown V / Percentage: 47.0V & 20% Recommended Low Batt V / Percentage: 49.0V & 30% Recommended Restart V / Percentage: 52.0V & 40% Battery Resistance: 5mOhms Battery Charge Efficiency: 99% Battery Empty Voltage: 46V

Dyness B4850 Battery Module

Batt Capacity: 50Ah x #Parallel_Batteries Max A Charge: 50A (25A for life) x #Parallel Batteries Max A Discharge: 50A x #Parallel Batteries Max A Grid Charge: 50A x #Parallel_Batteries TEMPCO: 0mV/C/Cell BMS Lithium Batt: 01 Float V: 53.8V Absorption V: 54.0V Equalization V: 54.0V Equalization Days: 30 Equalization Duration: 1 Hours (tops off battery) Recommended Shutdown V / Percentage: 47V & 20% Recommended Low Batt V / Percentage: 48V & 30% Recommended Restart V / Percentage: 49V & 40% Battery Resistance: 5mOhms Battery Charge Efficiency: 99% Battery Empty Voltage: 46V

Time	Watts	SOC	GridCharge
1:00AM	8000*Par_Batts	40%	
5:00AM	8000*Par_Batts	40%	
9:00AM	8000*Par_Batts	40%	
1:00PM	8000*Par_Batts	40%	
4:00PM	8000*Par_Batts	40%	
9:00PM	8000*Par_Batts	40%	

These settings will charge the batteries off solar only. Discharge the batteries down to a maximum of 40% full.

Limited To Home mode will not sell to the grid from the batteries (only the home will use battery power). The 100% time slot is to ensure that the batteries are properly cycled each day.

Time	Watts	SOC	GridCharge
1:00AM	2400*Par_Batts	40%	
5:00AM	2400*Par_Batts	40%	
9:00AM	2400*Par_Batts	40%	
1:00PM	2400*Par_Batts	40%	
5:00PM	2400*Par_Batts	40%	
9:00PM	2400*Par_Batts	40%	

These settings will charge the batteries off solar only. Discharge the batteries down to a maximum of 40% full.

Limited To Home mode will not sell to the grid from the batteries (only the home will use battery power).

MODBUS/RJ45 Application Note

BMS Lithium Batt Modes (Subject to Change):

00: CANBus Battery mode – Inverter also acts a ModBus slave with slave ID set by "ModBus SN Setting" (Pg. 29)

- 01: Storz ModBus Protocol
- 02: Pylontech ModBus Protocol
- 03: Old Blue Ion + eGauge / Polarium ModBus Protocol
- 04: Fortress Power ModBus Protocol
- 05: Kilovault HAB ModBus Protocol

06: Battery or Battery Controller is ModBus master and writes battery data to inverter's BMS registers (not currently in

use).



Find our full list of currently supported battery communications <u>www.sol-ark.com/battery-partners</u>

Our Battery Communications Integration Guide can also be found here <u>www.sol-ark.com/support</u>

Use the information below at your own risk; the warranty will not cover any damage caused by the improper use of the communications protocols. Read-Only Modbus Map available upon request at support@sol-ark.com

Combined RS-485 and CANBus	
PIN 1 OF 8 IS RS-485 B- (Data -) Pin 2 or 7 is $PS_{485} A + (Data +)$	Baud 9600
Pin 4 CAN High	8bits data
Pin 5 CAN Low	One stop bit, no parity
Pin 6 is GND	Does not require
	termination





Incorporating 3rd Party ModBus Devices:

If your device utilizes BMS Lithium Batt 00, you need to set the inverter Modbus SN to 01. The default ModBus SN is 00.



Troubleshooting Guide

LCD is not powering on

- Check all connections- at least one of the following power sources is required: PV/Grid/Battery
- Try pressing the power button, touchscreen, or navigation buttons

Panels are connected, but DC Light is not on

• PV voltage must be 150V-425V | It's night

Panels are not producing

- Check for proper wiring on all solar panel connections
- Turn PV disconnect "ON"
- Check that the PV input voltage is not greater than 425V
- If the system says PV = 0V, check the PV polarity

Panels are not producing much power

• PV Wire Strip Length: 5/8". Your batteries are charged; you can test Grid Sell to verify.

The system does not keep batteries charged

• Check the charge setting in the Charge Menu

Auto Gen-Start is not working

- Check to make sure your generator is compatible with Auto Start
- Make sure that the Auto Gen Start wire is adequately connected to the Sol-Ark 8K and the generator

Normal LED isn't on

- Sol-Ark 8K is in pass-through-only mode, with only a Grid connection.
- Sol-Ark 8K is not working correctly (Call us)

The alarm light is on

• Check the system alarms menu to identify the alarm

Grid HM value is negative when it should be positive (only applies in limited home mode)

• Limiter Sensors are backward, L1/L2 sensors are swapped, or incorrectly wired L1/L2 sensors. Try Auto Learn.

AC Overload Fault or Bus Unbalance Fault

- Check Transfer Switch/Subpanel wiring
- Check for large loads that consume more than the inverter rating (EX: AC units over 3 tons)

The system connects to the grid and quickly disconnects

- With a DMM, verify your Neutral wire connection (should be 0 Vac referenced to GND)
- Check your Freq is set to 60Hz, and the 8K measures 120V on L1 / L2 vs. N.
- If overloading: verify 120/240V grid input and load output wires are not swapped.
- If 120/208V, the L1 and L2 are phase-specific. So, you may have to swap Grid L1 / L2 for 208V applications.

DC Overload Fault

- Check PV voltage
- Make sure you have not wired more than two (2) solar strings in parallel

System is beeping

- Check the system alarms menu to see which alarm has been triggered. Most alarms will self-reset.
- There is no battery connected. If not using a battery, select no battery and disable activate batt in Batt menu.
 - Turn off the center button, remove AC Grid and PV Power for the 30s (screen is dead), and then power up to fully reset the system.

Battery cable sparks when connected

• Put the built-in battery breaker in the off position before connecting or disconnecting the batteries.

The battery symbol on the home screen is red

• The battery is under-Voltage or over-Voltage

The battery symbol on the home screen is yellow

• The battery is low, or the charge/discharge current is close to the programmed limit (which is ok)

The grid symbol on the home screen is yellow

• Grid parameters are out of specified range, or the grid is down

System has restarted

• It happens if the system is overloaded, the battery voltage is greater than 63V, or the Software update

Batteries were connected backward

• The battery breaker will trip. It can cause damage!

Why is the LCD screen still on when the power button is off?

• If PV or Grid power, LCD stays on, but the inverter and loads are off.

The Batt % meter is not reaching 100%

• The system needs to go through a small discharge/charge cycle first to calibrate the battery

The generator setup is reading 0Hz

• Select "General Standard" instead of UL1741. Then widen the frequency range to 55Hz-65Hz.

Color Touchscreen is Frozen

• Press and hold the escape button [←] for 7-10 seconds

Troubleshooting Phasing Issues



If the Sol-Ark screen shows **Grid Phase Wrong** there is a phasing issue with your wiring and it may cause overload faults (F18, F26, F34) even with the Load breaker off and WILL CAUSE DAMAGE if left unchecked.

Single Sol-Ark: To locate the improperly wired phases, measure L1 to L1 (Top Screws) between the Grid and Load breaker; you should see 0V AC. Repeat for L2 to L2 between the Grid and Load breaker. Attempt to correct the wiring until you are only reading 0V AC between L1 to L1 & L2 to L2.

Make sure to correct both the Grid and Load wiring; they both need to be correct.

If the error persists, you will need to check your AC wiring beyond the inverter and may also need to verify that the phases are properly labeled coming from your meter.

Sol-Ark 8K Error Codes

Fault	Instruction	Common Cause/Remedy
F1	DC Inversed Failure	If you have parallel systems and turn one system off, you with get this notification. Not a fault.
F8	GFDI_Relay_Failure	Current Leakage from inverter AC output to Ground, check Ground and neutral are connected at the main panel
F13	Grid_Mode_change	It can happen when not using batteries or if Grid Input settings are changed. This is a notification, NOT a fault. If you switch from No Batt to Battery mode, Power the System down completely to restart.
F15	AC_OverCurr_Failure	It is usually caused by Loads too large for the inverter. If off-grid, the battery discharge amps are programmed too low. Overloads can result in F15, F18, F20, or F26.
F16	GFCI_Failure	Ground fault. Check PV+ or PV- wiring (which must be ungrounded). Exposed PV conductors + rain can also cause. Check that the neutral line and Ground are not double-bonded (common with portable generators).
F18	Tz_Ac_OverCurr_Fault	Overloaded the Load Output: reduce loads. Wiring Short on the AC Side can also cause this error. Overloads can result in F15, F18, F20, or F26.
F20	Tz_Dc_OverCurr_Fault	It is typically caused by DC current from the battery that is too large (ex: 4 Ton AC Unit). Overloads can result in F15, F18, F20, or F26.
F22	Tz_EmergStop_Fault	Initiated Emergency Stop; see sensor pinout table.
F23	Tz_GFCI_OC_Fault	PV Ground fault. Check PV+ or PV- wiring (which must be ungrounded or damage can occur). Typically caused by pinched PV wire grounding the PV+ or PV Grounded PV wire can cause F20, F23, or F26.
F24	DC_Insulation_Fault	An exposed PV conductor combined with moisture is faulting (can cause F16, F24, F26).
F25	AC_Active_Batt_Fault	No battery connection to the Inverter and Activate Battery is enabled. Disable Activate Battery in settings while no battery is connected.
F26	BusUnbalance_Fault	Too much load on one leg (L1 or L2) Vs. the other leg or DC loads on the AC output when off-grid. Grounded PV wire can cause F20, F23, or F26.
F29	Parallel_CANBus_Fault	Usually, a communication error for parallel systems, check cables and MODBUS addresses
F30	AC_MainContactor_Fault	Contact Sol-Ark.com
F31	Soft_Start_Failed	Soft Start of large motor failed
F34	AC Overload Fault	AC Overload or load shorted. Reduce heavy loads.
F35	AC_NoUtility_Fault	Grid connection lost
F37	DCLLC_Soft_Over_Cur	Software DC overcurrent
F39	DCLLC_Over_Current	Hardware DC overcurrent
F40	Batt_Over_Current	Batteries exceeded their current discharge limit
F41	Parallel_System_Stop	If one system faults in parallel, this normal fault will register on the other units as they disconnect from grid
F45	AC_UV_OverVolt_Fault	Grid under voltage causes a disconnect. This will self-reset when grid stabilizes.
F46	Parallel_Aux_Fault	Cannot communicate with other parallel systems. Check Master = 1, Slaves are 2-9, ethernet cables are connected.
F47	AC_OverFreq_Fault	Grid over Frequency (common in power outages) causes a disconnect. Will self-reset when grid stabilizes.
F48	AC_UnderFreq_Fault	Grid under Frequency (common in power outages) causes a disconnect. Will self-reset when grid stabilizes.
F55	DC_VoltHigh_Fault	PV may be higher than 500V. Battery voltage should not be above 59V or 63V (depending on the model).
F56	DC_VoltLow_Fault	Batteries are overly-discharged, inverter is off grid and exceeded programmed batt discharge current by 20%, or Lithium BMS has shut down. If battery settings are incorrect, this can also happen.
F58	BMS communication fault	Sol-Ark is programmed to BMS Lithium Battery Mode but cannot communicate with a BMS
F60	Gen_Volt_or_Fre_Fault	Generator Voltage or Frequency went outside the allowable range
F61	Button_Manual_OFF	The parallel Slave system turned off without turning off Master
F63	ARC_Fault	It can be a lousy PV connector/connection. And sometimes a false alarm due to powerful lightning storms.
F64	Heatsink_HighTemp_Fault	Check the built-in fans are running; ambient temp may be too high



Y/N

Y/N

Y/N

For the installer to complete AFTER the system is operational. The purpose is to protect the installer, homeowner, and inverter.

- The 8K installed in a location where the LCD is protected from direct sunlight and has 6" clearance left and right for cooling Y/N 1.
- 2. Are all the battery lugs tightened?
- 8K should connect to the grid, 8K 63A load/Grid breakers ON, batteries connected, PV input on, and ON button on. With the 3. inverter running, the Backup load's panel and Grid-connected:
 - A. Did any breakers trip?
 - B. Did the inverter overload?
- If you have problems, please take pictures of these and email them to support@Sol-Ark.com 4.
 - A. Battery icon screen, showing detailed voltages (the screen shown below)
 - B. Sol-Ark 8K with batteries and user wiring area
- Load and solar test 5.
 - A. Press the battery icon for the detailed voltages screen.
 - B. Is the batt temp sensor working?
 - C. Turn on many loads for the Backup circuits. Are solar panels producing enough power to match the load (provided there is enough sun)? Y/N
 - D. Program Full Grid Sell Mode. If there are enough panels and sun or light loads in the entire house, the Grid HM Y/N measurements will be negative on both L1/L2. Are they negative (solar selling back to the grid)?
 - E. Program limited power to home mode. The Grid HM sensors will be near zero or slightly positive. Are they both near zero and canceling out the whole home power? Y/N
 - F. You have verified the limit sensors are correctly installed. An auto-learn function corrects any mistakes in CT limiter wiring (provided you have batteries and in 120/240V). Program in the correct Grid mode the customer will use.
- 6. Did you program the correct Ah for the battery bank and max Amps charge/discharge?
- 7. Did you program the correct battery charge voltages for your battery type?
- Turn off the AC breaker so 8K is operating in an off-grid mode for several minutes. Are appliances still powered? 8.
- Turn off the PV input, running only on batteries for several minutes. Are appliances still powered? 9. Y/N 10. Turn on the PV input and AC Grid inputs. 11. Did you set up the Wi-Fi plug to the customer's internet? Y/N Y/N 12. Absolutely important for software updates. Did you help the customer register system on Monitoring App? Y/N
- 13. Does the customer have a standby generator or a small portable Generator?
 - A. Did you turn off UL1741/IEEE1547 (use General Standard) and reprogram grid freq. range to 55-65Hz? Y/N
 - B. Did you enable Gen charging and adequately set the charge current if using a small gas generator on Gen inputs? Y/N Y/N
- 14. If EMP protected, did you install EMP Suppressors on essential appliance cords?

Installer Signature

Date

Customer Name

Customer Signature

Date

Y/N

Y/N Y/N

Y/N

This checklist must be filled out

and submitted to register your

warranty. Please visit:

https://www.sol-ark.com/register-

your-sol-ark/



5-Year Limited Warranty for SOL-ARK (Portable Solar LLC) Products. Sol-Ark provides a Five-year (5) limited Warranty ("Warranty") against defects in materials and workmanship for its Sol-Ark products ("Product"). The term of this warranty begins on the Product(s) initial purchase date or the date of receipt of the Product(s) by the end user, whichever is later. This must be indicated on your installer's invoice and bill of sale. This warranty applies to the original Sol-Ark Product purchaser and is transferable only if the Product remains installed in the original use location. Please call Sol-Ark to let us know if you are selling your Home and give us name and contact of the new owner.

The warranty does not apply to any Product or Product part that has been modified or damaged by the following:

- Installation or Removal (examples: wrong voltage batteries, connecting batteries backwards, damage due to water/rain to electronics, preventable damage to solar wires.)
- Alteration or Disassembly
- Normal Wear and Tear
- Accident or Abuse
- Unauthorized Firmware updates/software updates or alterations to the software code
- Corrosion
- Lightning: unless using EMP hardened system, then Portable Solar will repair product
- Repair or service provided by an unauthorized repair facility

ol-Ark

- Operation or installation contrary to manufacturer product instructions
- Fire, Floods or Acts of Nature
- Shipping or Transportation
- Incidental or consequential damage caused by other components of the power system
- $\boldsymbol{\diamond}$ Any product whose serial number has been altered, defaced or removed
- Any other event not foreseeable by Portable Solar, LLC

Sol-Ark (Portable Solar LLC) liability for any defective Product, or any Product part, shall be limited to the repair or replacement of the Product, at Portable Solar LLC discretion. Sol-Ark does not warrant or guarantee workmanship performed by any person or firm installing its Products. This warranty does not cover the costs of installation, removal, shipping (except as described below), or reinstallation of Products or parts of Products. LCD screen and fans are covered for 5 years from date of purchase.

THIS LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY APPLICABLE TO SOL-ARK (PORTABLE SOLAR LLC) PRODUCTS. SOL-ARK EXPRESSLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTIES OF ITS PRODUCTS. SOL-ARK ALSO EXPRESSLY LIMITS ITS LIABILITY IN THE EVENT OF A PRODUCT DEFECT TO REPAIR OR REPLACEMENT IN ACCORDANCE WITH THE TERMS OF THIS LIMITED WARRANTY AND EXCLUDES ALL LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION ANY LIABILITY FOR PRODUCTS NOT BEING AVAILABLE FOR USE OR LOST REVENUES OR PROFITS, EVEN IF IT IS MADE AWARE OF SUCH POTENTIAL DAMAGES.

Return Policy - **No returns will be accepted without prior authorization** and must include the Return Material Authorization (RMA) number. Please call and talk to one of our engineers to obtain this number at 972-575-8875.

Return Material Authorization (RMA) A request for an RMA number requires all of the following information: 1. Product model and serial number; 2. Proof-of-purchase in the form of a copy of the original Product purchase invoice or receipt confirming the Product model number and serial number; 3. Description of the problem; 4. Validation of problem by Technical Support, and 5. Shipping address for the repaired or replacement equipment. Upon receiving this information, the Sol-Ark representative can issue an RMA number.

Any product that is returned must be brand new, in excellent condition and packaged in the original manufacturer's carton with all corresponding hardware and documentation. Returns must be shipped with prepaid freight and insured via the carrier of your choice to arrive back at Portable Solar within 30 days of your initial delivery or pick-up. **Shipping charges will not be refunded**.

All returns are subject to a 35% restocking fee. **No returns will be accepted beyond 30 days of original delivery.** The value and cost of replacing any items missing (e.g. parts, manuals, etc.) will be deducted from the refund. If you have any questions regarding our return policy, please email us at <u>sales@sol-ark.com</u> or call us at the number above during regular (M-F) business hours.

Sol-Ark 8K Install Operational Verification Checklist Questionnaire must be filled out, signed, and dated to secure full warranty coverage.

For Info/Purchasing: <u>sales@sol-ark.com</u> | ext.1 For Tech Support/Warranty Claim: <u>support@sol-ark.com</u> | ext.2

Contact Us: 1-972-575-8875

For Administrative Help:

ext.3