



Quick Installation Instructions



After unpacking, inspect the product and packing list. If the product is damaged or any parts are missing, please contact your local dealer.


Step 1

Remove the battery top cover to provide space for installation.




Step 2


Install the wiring trough and busbars in the designated positions on top of the battery, as shown in the diagram.



Fixing Bracket
1 PC



Sealing Rubber
Strip
1 PC



Busbar
2 PCS



Waterproof
Plug
2 PCS



Insulating
Spacer
4 PCS



Cabinet Screw
8 PCS



Cover Screw
12 PCS



Battery Wire
Screw
8 PCS




Busbar
Locking Screw
4 PCS




Negative
Battery Wire
1 PC



Positive
Battery Wire
1 PC




(2-1)



(2-2)


Step 3

Secure the wiring trough cover to the wiring trough body. Then apply the sealing rubber strip evenly around the perimeter of the cover.




Step 4

Install the wall-mounting brackets for the inverter and battery. Maintain the spacing between the two bracket sets exactly as shown in the diagram.



Step 5

Install and secure the inverter on the wiring trough. Connect the inverter cables to the corresponding busbar terminals.



Step 6

Finally, install and secure the wiring trough cover to complete the installation.

