

#### Features:

- Universal AC input / Full range
- Programmable output Voltage (0% ~ 105%)
- Programmable output Current (0% ~ 105%)
- **Built-in active PFC Function**
- Forced current sharing at parallel operation (Refer to pg. 5 for connection diagram)
- **Constant current limit**
- Selectable +5V / 0.5A or +9V / 0.3A auxiliary output
- Global control via RS232
- Remote setting multiple via RS232, RS485 & I2C
- **Power OK signal**
- Remote ON / OFF function
- Protection: OVP, OLP, OTP, SCP, Fan failure








MODEL		AEK-3000-150	AEK-3000-200	AEK-3000-250	AEK-3000-300	AEK-3000-400		
	DC Voltage Rated	150V	200V	250V	300V	400V		
	Rated Current	20A	15A	12A	10A	7.5A		
	Current Range	0 ~ 20A	0 ~ 15A	0 ~ 12A	0 ~ 10A	0 ~ 7.5A		
	Rated Power	3000W						
	Ripple & Noise (Max.) Note.2	1500mVp-p	2000mVp-p	2500mVp-p	3000mVp-p	4000mVp-p		
Output	Voltage Adj. Range	±5.0% Typical adjustm	ent by potentiometer. (	Via V-Adi from PSU fro	nt panel)			
·		3 ±2.0% (rated output voltage of single unit)						
	Current Tolerance	±3.0% (rated output current of single unit)						
	Line Regulation	±1.0%						
	Load Regulation	±1.0%	:1.0%					
	Setup, Rise Time	1100ms, 350ms at full load						
	Hold Up Time (Typ.)	14ms / 230VAC at full load						
	Frequency Range	90 ~ 264VAC, 127 ~ 370VDC (Refer to de-rating curve) 47 ~ 63Hz						
	Power Factor (Typ.)	0.95 / 230VAC, 0.98 / 1	115\/ΔC at full load					
Input	Efficiency (Max.)		110V/10 at fall load					
	AC Current (Max.)	93%						
	Inrush Current (Typ.)	19.7A / 115VAC (2000W), 14.5A / 230VAC (3000W)						
	Leakage Current	33A / 115VAC, 65A / 230VAC						
	Leakage Current	< 3.5mA / 240VAC						
	Over Load	105% rated output power						
Don't at the		Protection type: Constant current limit						
Protection	Over Voltage	Variable OVP Refer to VCI VS OVP curve.(OVP Tolerance 7%)						
		• • • • • • • • • • • • • • • • • • • •		eset AC power ON or in				
	Over Temperature	85 ±5°C detect on NTC	* **		ture goes down			
	Auxiliary Power	Selectable +5V / 0.5A	or +9V / 0.3A auxiliary o	output				
	Remote ON / OFF Control	By external switch						
Function	Power OK Signal				Max. drain voltage: 40V.			
	Output Voltage Trim	Adjustment of output voltage is between 0 ~ 105% of rated output						
	Output Current Trim	Adjustment of output current is between 0 ~ 105% of rated output						
	Parallel (Current Sharing) Note.5 Please refer to page 5							
	Working Temp.	-20 ~ +60°C (Refer to	de-rating curve)					
	Working Humidity 20 ~ 90% RH non-condensing							
Environment	Storage Temp. & Humidity	-40 ~ +85°C, 10 ~ 95%	RH					
	Temp. Coefficient	±0.02% / °C (0 ~ 50°C)						
	Vibration	10 ~ 500Hz, 2G 10min.	1cycle, period for 60min	. each along X, Y, Z axes	Compliance to IEC 60068	3-2-6, IEC 60068-2-64		
	Safety Standards	Certified EN 62368-1;	UL62368-1					
	Withstand Voltage Note.7	I/P-O/P:3KVAC(4242V	DC),I/P-FG:1.5KVAC(2	121VDC),O/P-FG:0.5K	VAC(707VDC)			
Safatu & EMC	Isolation Resistance	I/P-O/P, I/P-FG, O/P-F	G: 100M Ohms / 500V	OC (25°C/70%PH)				
Safety & EMC	EMI Conduction Radiation	Certified EN 55032						
	Power Harmonic & Voltage Fluctuation and Flicker	Certified EN 61000-3-2	2; EN 61000-3-3					
	EMS Immunity	Certified EN 55024: IF	C 61000-4-2,3,4,5,6,8,	11				
	Cooling	Load and temperature		••				
Others	Dimension (WxHxD)	170x64x280 mm / 6.69						
Cuisio	Packing							
Note	3.3kg; 6pcs / 22.7kg / 2.48CUFT							



## Mechanical Drawings:

Unit:mm / inch



Recommended screw length is measured from the power supply surface

AC Input Terminal Pin No. Assignment

Pin No.	Assignment
L	ACL
N	ACN
÷	÷

000000000000 

Control pin number assignment (CN5): JST S24B-PHDSS or equivalent

Pin No.	Assignment	Pin No.	Assignment	Pin No.	Assignment	Mating Housing / Contact	
1	NC.	9	EN-	17	AUX		
2	NC.	10	GND	18	GND		
3	NC.	11	EN+	19	SCL		
4	NC.	12	AUX	20	SDA		JST SPHD-002T-P0.5
5	POK	13	ACI	21	AUX	or equivalent	or equivalent
6	GND	14	GND	22	GND		
7	PAR	15	VCI	23	RX		
8	VSET	16	GND	24	TX		

# CN5 Function Description:

Pin No.	Function	Description	Pin No.	Function	Description	
1	NC.		13	ACI	I Program	
2	NC.		14	GND	Ground	
3	NC.		15	VCI	V Program	
4	NC.		16	GND	Ground	
5	POK	Power OK	17	AUX	+5V / 0.5A or +9V / 0.3A Auxiliary power	
6	GND	Ground	18	GND	Ground	
7	PAR	Parallel operation current share	19	SCL	Serial Clock used in the I <sup>2</sup> C interface	
8	VSET	Aux output setting	20	SDA	Serial Data used in the I <sup>2</sup> C interface	
9	EN-	Inhibit ON/OFF (-)	21	AUX	+5V / 0.5A or +9V / 0.3A Auxiliary power	
10	GND	Ground	22	GND	Ground	
11	EN+	Inhibit ON/OFF (+)	23	RX	For RS232 Receiver function	
12	AUX	+5V / 0.5A or +9V / 0.3A Auxiliary power	24	TX	For RS232 Transmission function	





### **LED Status:**

LED	LED Signal	Status	
Solid(Green)		Power OK (Local mode)	
Solid(Orange)		Power OK (Remote mode)	
Slow Blink(Green)	 	Power Standby (Local mode)	
Slow Blink(Orange)	1	Power Standby (Remote mode)	
Fast Blink(Red)		Over Voltage Protection ( OVP )	
Solid(Red)		Over Load Protection ( OLP )	
Slow Blink(Red)		Over Temperature Protection ( OTP )	
Intermittent Blink(Red)		Fan Failure	
Interlace Blink(Red)		Power Failure	


<sup>\*</sup>Local mode: Use ACI/VCI control output current and voltage. Remote mode: Use RS-232 or I<sup>2</sup>C command control output current and voltage.

## **De-rating Curve:**







# **CMD VS Output Curve:**



# **VCI VS OVP Curve:**




To ensure the power supply output voltage and current could be accurately adjusted, please make sure to adjust the output voltage and current > 10% vs. the rated voltage and current. (e.g. for a 300V unit, please adjust the DC output voltage above 30V to ensure accuracy; same applies to the output current)





#### Remote ON/OFF:




<sup>\*</sup>GND shown in above diagram is referring to the GND of CN2, not the Grounding from main power(NEG-).\*


## **Power OK Signal & Auxiliary Power Setting:**

\*The grounding of "AUX" power and P.OK signal should be connected to "GND" port. If " VO-" is connected as Grounding, make sure to short the GND and VO- ports.

Open drain signal low when PSU turns on, Max. P.OK sink current: 20mA, Max. drain voltage: 40V.



\*Place an additional capacitor to have a better performance of auxiliary power operation.




Do NOT exceed 5V/0.5A or 9V/0.3A

<sup>\*</sup>GND shown in above diagram is referring to the GND of CN2, not the Grounding from main power(NEG-).\*



#### 1. Current Sharing




Please connect PAR pins together for current sharing function For Series connection, make sure to isolate CN2 control signals



### **Installation Instruction:**

#### 1. Mounting Directions

1-1 Recommended standard mounting methods:



Recommended screw length is measured from the power supply surface

#### 2. Mounting Method

- 2-1 There are ventilating holes on the front and back side panels, do not obstruct; allow 50mm at least for air flow.
- 2-2 The Maximum allowable penetration of screw is 3mm. Incomplete threading should not be penetrated.
- 2-3 Recommended the torque of mounting screw: M4 screw: 1.27N • m (13.0kgf • cm)

